

FALSE ALERT CANCELLATIONS PROCEDURES (Рез. 349 (wrc-23))

FALSE ALERT TRANSMITTED BY:

MF DSC or VHF DSC

HF DSC

NO

Is DSC unit in automatic repetition?

YES

Следовать инструкциям на экране радиостанции или выключить её на 10 с. (Рез. 349 (wrc-23))

Cancel by DSC; Set Equipment to Channel 16

Set DSC Equipment ON

Cancel by DSC; Set Equipment to 2182 kHz

Set DSC Equipment ON

Make broadcast to "All Stations":
MAYDAY ALL STATIONS - 3 times
This is NAME - 3 times, CALL SIGN or other ID, MMSI
PLEASE CANCEL MY DISTRESS ALERT OF _____ TIME UTC
OVER

NO

YES

Is DSC unit in automatic repetition?

NO

Следовать инструкциям на экране радиостанции или выключить её на 10 с. (Рез. 349 (wrc-23))

Cancel by DSC. Tune equipment consecutively to all the radio telephony distress frequencies on which the false alert was transmitted: 4, 6, 8, 12, 16 MHz

INMARSAT C, mini-C,

Notify the appropriate RCC to cancel the alert by sending a *distress priority* message via the *same* LES through which the false distress alert was sent:
MAYDAY; NAME, CALL SIGN, Inmarsat-C IMN; PSN; Cancel my distress alert of DATE, TIME UTC =Master+

EPIRB

If an EPIRB is accidentally, **switch off EPIRB** and contact the **nearest coast station** or appropriate **LES** or **RCC** or **MCC** and cancel the distress alert